

# **Pattern and Probe-Based Aberration Monitors for the Human Eye**

e-beam lithography

E298A/EE290B

May 13, 2003

Garth Robins


Applied Science & Technology,  
University of California, Berkeley, CA

# Outline

- Introduction to aberrations
- Pattern and probe-based aberration monitors
  - Sensitivity
- Application to aberrations in human eyes
- Process flow & results
- Proposed experimental setup
- Summary: Proposed new process


# What is an aberration?

- Small opening in chrome fills entire pupil with scattered light
- Spherical wavefront incident upon lens
- **Form & figure** errors along w/ **inhomogeneity** of lens material results in deviation from sphericity upon exit
- Hecht: “...deviations in OPL b/w actual & ideal wavefronts...[ $\mu\text{m}$ ], [nm], or [ $\lambda$ ].”




# Aberrations Over a Circular Pupil (2-D)

- Targets designed to **quantify individual Zernike aberrations** to  **$1/100 \lambda$  rms**
- Each target has a **probe** ( $0.4 \lambda/\text{NA}$ ), surrounded by a **pattern** on the mask
- Optimum pattern is the Inverse Fourier Transform (IFT) of Zernike of interest
- **Even/odd** aberrations require  **$90^\circ/0^\circ$**  probe
- Light scattered by target rings interacts with aberrations in lens, spilling light into **center probe region** at image plane




Phase  
yellow =  $0^\circ$   
green =  $90^\circ$   
red =  $180^\circ$

mask






lens



wafer

# Target Sensitivity and Orthogonality



Phase  
 yellow = 0°  
 green = 90°  
 red = 180°  
 0.4 λ/NA probe


$\sigma = 0.1$	Targets				
$\delta$ -peak with 0.01 λ rms of	Defocus	Spherical	HO Spherical	Coma	HO Coma
No Aberration (peak value)	0.933	0.242	0.207	0.555	0.222
Defocus	+0.220	-0.034	-0.021	<+0.01	< -0.01
Spherical	<+0.01	+0.256	-0.056	<+0.01	<+0.01
HO Spherical	-0.084	-0.063	+0.299	<+0.01	<+0.01
Coma	+0.020	<+0.01	<+0.01	+0.299	-0.038
HO Coma	<+0.01	<+0.01	<+0.01	< -0.01	+0.249

# VSIA-99 Standards Taskforce


## (OSA)

Vision Science and its Applications  
Optical Society of America

Clinician's View of Patient




- Coordinate system
- Resolved to use Zernikes
- Give aberrations wrt entrance pupil b/c image space is generally inaccessible




# Biology Lesson: The Human Eye

- Highly complex imaging system
- Decentered optical system with non-rotationally symmetric components
  - cornea, aqueous humor, iris, crystalline lens, vitreous humor, retina, rods & cones, fovea (macula)
- Varying “film grain”
- Foveola has the highest concentration of cones & covers just  $< 1^\circ$  in angular extent (0.35mm diam.)
- We rotate our eye so that the object of interest images to the foveola
- Ability to see fine details most strongly affected by aberrations at the foveola (coma dominates) VSIA-99




# GDS of Zernike Targets


Z3 defocus




Z4 astigmatism




Z14 HO coma




Z7 coma




Z10 3-foil




Z15 HO spherical




Z8 spherical



Z11 HO astigmatism



Z16 4-foil




Probe diameter  
 $\sim 0.45 \lambda/\text{NA}$

Thickness of each annulus  $\sim 0.52 \lambda/\text{NA}$



# Simplified 3 Phase Mask Flow 1



- 4" Hoya wafer
- 1030Å cr on quartz
- 0.5μm KRS-XE 11.6% (1000rpm)
- 4 different doses
- **Step 1:** open chrome for 90° (346μm) and 180° (692μm) phase shift regions.
- Cr etch
- Strip resist & use cr as etch mask
- QZ etch 90° (~356μm)



- QZ etch:  $5 + 8 + 2 + \frac{1}{2} + \frac{1}{2}$  min. = 16 min.
- Cr + QZ etch = 230, 390, 439, 444, 456nm






# Simplified 3 Phase Mask Flow 2

- **Step 2:** open resist for  $180^\circ$  (+346 $\mu\text{m}$ , ttl. = 692 $\mu\text{m}$ ) phase shift regions.
- Use chip with windows to measure resist etching
- Windows moved (!)
- QZ etch +23 min. (!) + $90^\circ$  (ttl. w/o cr ~ 833 $\mu\text{m}$ )
- Appears to have etched away all resist as well, possibly exposing the  $90^\circ$  probes to overetching




# Simplified 3 Phase Mask Flow 3

- **Step 3:** open cr for 0° rings & probes
- Cr etch



# Proposed Experimental Setup 1



# Summary

- Processing on three phase “mask” for the detection of Zernike aberrations in the human eye taken to final stage.
- Second quartz etch was too deep, but would have been correct if appropriate time used.
- New process: open  $0^\circ$  regions in cr, then  $90^\circ$  &  $180^\circ$  regions ( $90^\circ$  QZ etch), open  $180^\circ$  regions ( $+90^\circ$  QZ etch) (still requires 3 lithos. & can't use cr as hard mask)

# References

- Thibos LN. Wavefront data reporting and terminology. J Refract Surg (2001) 17; S578-583
- J Refract Surg 2002 Sep-Oct;18(5):S652-60 Standards for reporting the optical aberrations of eyes. Thibos LN, Applegate RA, Schwiegerling JT, Webb R; VSIA Standards Taskforce Members. Vision science and its applications.
- G. Smith & D. Atchison, The Eye and Visual Optical Instruments, Cambridge University Press, 1997.

**THE END**