High energy electron beam lithography on self-assembled monolayer of 3-aminopropyltriethoxysilane

Class project, EE290b Spring 2003


Yu-Chih Tseng, dept. of EECS, UCB

Carbon nanotubes

- Carbon nanotubes (CNT) is a promising candidate for electronic application:
 - Higher current
 - Higher gain
- Diameter of CNT is about 1 to 5 nm
 - How to manipulate?

Self assembly of nanotubes


 Nanotubes can be deposited selectively on a patterned substrate of functionalized with amines



K.H. Choi, Surf. Sci. 462 (2000) 195-202

Self-assembly of nanotubes

CNT selectively adheres to hydrophilic surface




 Direct patterning of trimethylsilane monolayer, followed by deposition of 3-aminopropyltriethoxysilane (APTES)

J. Liu et al, Chem. Phys. Lett. 303 1999 125–129

Direct patterning of APTES


3-aminopropyltriethoxysilane:



- Silane binds to silicon oxide surface
- NH₂ binds to the nanotubes
- •E-beam: destroys the amine groups

Previous results

•Patterning at low voltages (1keV) is feasible




Dose $\sim 100 \,\mu\text{C} \,/\,\text{cm}^2$

This work

- Pattern APTES using 100keV electron beam
- Dose = 1000 to 10000 μC/cm²
- Make very small features on APTES to see how alignment of CNT may be improved


Layout



- •Row 1: 100 nm lines and spaces
- •Rows 2 to 4: 12 x 12 squares, from 100nm to 10nm


Process Flow – step 1

 Patterning of Cr/Au alignment marks by lift-off




Process flow – step 2

- Oxygen plasma cleaning
- Deposition of APTES monolayer: standard recipe in molecular biology



Process flow – step 3

 Monolayer patterning: align to markers and expose patterns (5 um, 5 um) relative to the center of cross.




Characterization

- Tapping mode AFM
- Functionalized gold particles with citrate groups: selective adhesion to amines.


SEM results

Non-uniform surface




SEM results

Need improved monolayer deposition



SEM results

Nanoparticles: density is too low



- Mean spacing is 100nm
- Expected: 10nm, calculated using known concentration and volume used

Nanoparticles

- Mean diameter is 10nm
- ◆ To cover a 4" wafer, need ~10¹⁴ particles
- Used 3ml solution with concentration of 6x10¹² particles / ml. over 20 cm²
- .:Nanoparticle sticking efficiency seems low

Summary

- Exposure of APTES monolayer at 100keV attempted
- Dose required seems very high
- Characterization is difficult

Future work

- Improve monolayer deposition
- Improve characterization: use particles that stick to exposed surface only
- Contact mode AFM / lateral force microscopy

Acknowledgement

- Alex Liddle
- Erik Anderson
- Weilun Chao
- Bruce Harteneck
- Farhad Salmassi